

## Supplementary Instructions for PS536 Gas Conversion Kits 45734 and 45735

As of 9/10/01, PS536 domestic (non-CE) natural gas ovens use a baffle around the cooling fan, as shown in the illustration below. Propane ovens do not use the baffle.

This Supplement updates PS536 Gas Conversion Kit instructions with the correct procedures to install this baffle (for propane-to-natural gas conversions) or to remove it (for natural gas-to-propane conversions).

Note that if a PS536 oven is to be converted from propane to natural gas operation, the following additional parts should be available:

- Cooling fan baffle, P/N 46591 (1 reqd.)
- Screw, hex washer head, #12-14 x 3/4", stainless steel, P/N 21296-0005 (2 reqd.)

**DURING THE GAS CONVERSION KIT INSTALLATION, PERFORM ONE OF THE FOLLOWING PROCEDURES BEFORE REPLACING THE BACK WALL OF THE OVEN.**

### *FOR NATURAL GAS TO PROPANE CONVERSIONS:*

1. Check for the presence of a cooling fan baffle below the cooling fan, as shown below.
2. If the baffle is present, remove and discard it. Continue on with the gas conversion kit instructions.

### *FOR PROPANE TO NATURAL GAS CONVERSIONS:*

1. Check for the presence of a baffle between the burners and the cooling fan, as shown below.
2. If the baffle is present, continue on with the gas conversion kit instructions.
3. If the baffle is NOT present, install it as shown in Figure 1 below using #12-14 x 3/4" stainless steel self-tapping screws (Middleby P/N 21296-0005). On some ovens, there will be two mounting holes for the baffle already present on the burner support bracket.
4. Continue on with the gas conversion kit instructions.

